



The concrete columns sticks out from the wall 4 inches and are 16 inches wide. The edge of the concrete is 21 feet from the back wall of the stage. There is a valance that hides the center projector screen that protrudes down from the ceiling about 18" (black rectangle at the back of the stage). The two side screens are set tight against the concrete columns and have about 4 inch frames around the 9'x11' screens. The walls on the left and right sides of the stage are symmetrical.

